

EMD (GM) SPARE PARTS LIST		
SL. NO.	ITEM DESCRIPTION	PART NUMBER
1	BUSHING ARM	9571921
2	SHAFT GOVERNOR DRIVE	9514175
3	CAP ROCKER ARM	9090608
4	SHAFT GOVERNOR DRIVE	9514175
5	STUD	9574852
6	FLEXIBLE HOSE PIPE(BIG)	9320121
6	FLEXIBLE HOSE PIPE (SMALL)	9320122
8	CLAMP	9131881
9	CLAMP	9181284
10	CLAMP	9198177
11	BOLT SPLINE HEAD	9434253
12	SHAFT GOVERNOR DRIVE	9514178
13	CAP SUPPORT	9090608
14	STUB SHAFT	9546333
15	RING RETAINING	9413182
16	BOOSTER PUMP HOSE (BIG)	9320121
17	BOOSTER PUMP HOSE (SMALL)	9320122
18	ANNEXURE FOR ST CON TRACTOR	9325207
19	NUT SPECIAL	9338626
20	RING DAMPER OUTER	9323944
21	BRACKET ASSEMBLY	40047142
22	BRACKET SUPPORT	40047156
23	FLEXIBLE HOSE PIPE (SMALL)	40030891
24	FLEXIBLE HOSE PIPE (BIG)	40054733
25	BUSHING FOR BRAKE	40026004
26	'O' RING	40122943
27	'O' RING	40083645
28	POWER ASSEMBLY(BLADE ROD)	40028015
29	BUSHING	4002604/40023405/40023552
30	PIN ASSEMBLY BLOCK MOUNTING	40023308
31	PIN ASSEMBLY BRAKE HEAD	40023227 / 40023259
32	PIN HANGER INSIDE	40077219
33	PIN GOVERNOR	442919
34	CLAMP	400370360
35	PIN HANGER OUT SIDE	40077220
36	SET OF OVERHAULING BRAKE	40055299
37	SPECIAL WASHER	40087021
38	'O RING	40122943
39	PIN ASSEMBLY	40023227
40	PIN ASSEMBLY	40023308
41	SPACER TURBO	40028614
42	OST ASSEMBLY GUIDE SPRING / WEIGHT TRIP	40026945 / 40026944

43	SPACER TURBO CHARGER	40028614
44	WASHER BELLEVILLE	40016368
45	SET OF SPARES BRAKE PIN ASSEMBLY	40023308
46	PIN DRILLED HEX HEAD	40023309
47	RING	40076190
48	RING WEAR	40074162
49	BUSHING	40076287
50	PIN SPRING	456652
51	PIN	453676
52	PIN	455481
53	PIN	457008
54	PIN SPRING	455972
55	GOROOVED PIN	442919
56	RING SNAP	40075229
57	GASKET	40039280
58	SPACER FLANGED	40075183
59	SPACER	40075126
60	RING SNAP	40075229
61	BUSHING TRACTION BAR	40090979
62	SPACER	40075126
63	RING SNAP	40075229
64	LINK	40083645
65	WASHER SPECIAL	40087021
66	BUSHING	40026004
67	PIN SPRING	456652
68	PIN SPRING	455481
69	PIN TYPE BOGIE	442919
70	WASHER FLAT	446211
71	FUEL CONTROL LINKAGE PIN(SMALL)	8080078
72	FUEL CONTROL LINKAGE PIN (BIG)	8194550
73	BUSHING FOR BRAKE	8052336/8068058/8336929 /8052334
74	BUSHING FOR BRAKE	8059991/8197960/8915447 /8065520
75	DRIVE ASSEMBLY	8175893
76	SPACER GOVERNOR DRIVE GEAR	8028365
77	GEAR WATER PUMP DRIVE	8042976
78	BOLT HEX HEAD	8080078
79	NUT HEX LOCK	8060089
80	WASHER FLAT	8028733
81	BOLT HEX HEAD	8194650
82	HEX LOCK NUT	8032716
83	PIN	8028103
84	GOVERNOR DRIVE HOUSING	8175893
85	DOWEL THRADED	8028738
86	BOLT HEX HEAD	8194650

87	BUSHING	8052334 / 8200401
88	NUT SPLINE	8081581
89	STUD	8084872
90	STUD	8084871
91	PIN DOWEL	8028366
92	PIN ASSEMBLY ADJUSTER	8333166
93	PIN ASSEMBLY CLEVIS	8401933
94	STUD	
95	PIN CLEVIS	8028103
96	CLAMP	8355744
97	CLAMP	8168456
98	LINK ASSEMBLY ADJUSTING	8070027
99	WASHER SPECIAL	8483090
100	CAP BEARING	8418657
101	COVER BEARING	8418656
102	WASHER SPECIAL	8427242
103	NUT SELF LOCKING	8060089
104	DOWEL	8022474 / 8022476
105	OST ASSEMBLY – BOLT HEX, NUT HEX, DOWEL,	8059643/8032715/8028739
	POWER OST, ANCHER SPRING,SPRING POWEL	/
		8069264/8028212/8028791
106	BOLT SPLINE HEAD	8348718
107	PLUNGER LOWER UNLOADER	8057452
108	NUT IMPELLER	80287240
109	NUT GEAR	8032724
110	SLINGER	8042969
111	SPRING WATERPUMP	8055346
112	STUD LOCKING	8034672
113	WASHER SPECIAL	8140912
114	BUSHING SHEAVE	8200401
115	SET ITEMS OF BRAKE PIN ASSLY	8333166/8333178/8401933
		/8449521
116	BUSHING GEAR	8360546
117	DOWEL	8028738
118	SEAL OUTER	8405527
119	LINK ASSEMBLY	8070027
120	SEAL 'O' RING	8342588
121	SEAL STUB	8294874
122	GEAR GOV. DRIVE	8028499
123	GEAR GOV. DRIVE	8028238
124	SHIM BEARING	8061581
125	LEVER INJECTOR	8360051
126	SPACER CONTROL LEVER	8054047
127	WASHER SPECIAL	8140912
128	PIN CAM FOLLOWER	8146111
129	GEAR DRIVE 24 TEETH	8028499

130	PIN CLEVIS	8028098
131	RING SNAP BEARING	8054053
132	LOCK NUT HEXAGONAL	8028724
133	SEAL OIL	8028752
134	GOVERNOR CONTROL LINKAGE	8080478
135	BOLT HEX HEAD	8194650
136	NUT HEX HEAD	8032716
137	GASKET GOVERNOR	8028209
138	AUSILIARY GEN. VALVE DRIVE(12 ITEMS)	8460738
139	AUX. GEN. VALVE DRIVE ASSLY	8460738
140	WASHER SPECIAL	8042977
141	RHEOSTAT ASSLY DYNAMIC BRAKE	8354311
142	WASHER FLAT FOR WATER PUMP	8028730
143	BOLT ASSEMBLY WITH SPACER	8159340
144	WOOD RUFF KEY	108627
145	BOLT HEX HEAD	181377
146	RETAINING SPRING	148151
147	OST ASSEMBLY-WASHER/NUT/W.R.KEY/PIN CLEVIS	1116097/114498/124548/1 14785
148	BOLT HEX HEAD	181339
149	WASHER LOCK	120214
150	KEY GEAR SIDE	108627
151	KEY IMPELLER	103909
152	KEY WOODRUFF	103909
153	KEYWOODRUFF	108627
154	RETAINER CLEVIS	148147
155	SET OF ITEM FOR BRAKE PIN ASSLY	108268/103326/103399/10 6270/121326
156	PIN CLEVIS	10610527
157	SPRING DETAINED	10563303
158	PIN SWIVAL	10563288
159	SPRING REVERSON	10563289
160	SPRING CLEVIS	10592530
161	RING RETAINER	10610509
162	SPRING PLUNGER	01600532
163	SOCKET BLUB	10563353
164	HANDLE DIRECTIONAL	10563802
165	BRACKET	10600531
166	SCREW FLT HEAD	10563376
167	DRUM READ OUT	10563315
168	BEARING ½"	10574188
169	BEARING ½"	10563311
170	THROTTLE HANDLE SHAFT	10592349
171	CLEVIS ASSEMBLY	10563274
172	ARM ASSEMBLY	10563284
173	BEARING 3/8 DIA	10600531

174	BRACKET THROTTLE	10563317
175	BEARING 7/16 DIA	10563591
176	KNOB THROTTLE	10600532
177	SPRING PLUNGER	10600532
178	SILICON 'O' RING	182345
179	KEY WOOD RUFF FRONT REAR DRIVE GEAR	1179882
180	SET OF BOLT WASHER –BOLT,WASHER,BOLT SPLINE	181339/120214/8348718
181	GEAR RACK	5226147
182	NUT SLOTTED	218493
183	NUT SLOTTED HEX	218504
184	RING RETAINING	274612
185	PIN RETAINING	273337
186	NUT HEX	218445
187	SIDE PANEL GASKET	206584
188	GASKET GOV.SUPPLY OIL	206148
189	GASKET POWER PISTON	206165